
- 1. Technology: Solar PV
- 2. Maximum Power: 60 kW
- 3. Contribution to fault levels: N/A
- 4. Size & rating of the relevant Transformer: N/A
- 5. Single line diagram: refer to following page
- 6. Protection Systems & Communication Systems: refer to following page
- 7. Voltage Control and reactive power capability: N/A8. Details specific to the location of facility: N/A





Library of Setpoints

For Mainspro

<u>a</u> .	ALS IANGSESSA MAIS AL	
	DEFAULT SETTINGS	INSTALL SETTINGS
Uin	230/400	
System	3PH	
DispT [min]	2 mins	
Auto FR	Disabled	
Auto FR Del [s]	0	
Start Trip	Disabled	
Imp Len [s]	1	
Bak Trp Del [s]	0	
Ext	Enable	
F.R	Enable	
Alt	Disable	
Disable	Disabled	
V>	270V	260V
V> Del	1 sec	1-5 SEC'S
V>>	0	
V>> Del	0 sec	
V<	203V	210V
V< Del	1.5 sec	1.5 SECS
V<<	0	
V<< Del	0 sec	
Avg V> [V]	0	
Rs(V>, V>> [%V>]	0	
RstV<, V<< [%V<]	0	
V unb, A.V unb [V]	0	
V< pos, A.V < pos [V]	0	
V> neg, A.V> neg [V]	Ō	
Du del, A.dU del [s]	0	
* * * · · · · · · · · · · · · · · · · ·		The state of the s

	DEFAULT SETTINGS	INSTALL SETTINGS
F>	50.7 Hz	50-7 HZ
F> Del	1 sec	1.2 secs
F<	49.5 Hz	49-5 HZ
F< Del	1 sec	1-2 SECS
F>>	0	
F>> Del	0	
Rstf>, f>> [%f>]	0	
RSTF<, f<<	0	
VS lim, A.VS lim [⁰]	12	8
ROCOF, A.ROCOF [Hz/s]	1 Hz	IHZ /SEC
ROCOF filt, A.ROCOF Filt [-]	50	
LOM Init Del, A.LOM Init Del[s]	2 sec	
LOM Trip Del, A.LOM Trip Del[s]	2 sec	
BI1 Ext	BI1 = Ext	
BI2 F.R	BI2 = N/A	,
BI3 Alt	BI3 = N/A	
BI4:Dis	BI4 = N/A	· · ·
Default Settings	RE1:!CommTrpPer	
The state of the s	RE2:!InternFail	
	RE3:!BackTrpImp	
The state of the s	RE4:!InternFail	
	RE5:TrpEndImp	